


Flow optimiser + inletring



DucoBox Energy Comfort D400 / Plus

L2004682-A 21.05.2024



Service & Maintenance
 DucoBox Energy Comfort D400
 and Comfort Plus fans



Situation BEFORE and AFTER

<p style="text-align: center;">Fan with "old" inlet ring DucoBox serial number before Pxxxx-240506-xxx</p> 	<p style="text-align: center;">Fan with flow optimiser + (new) inlet ring DucoBox serial number as of Pxxxx-240506-xxx</p> 
--	--

Assembly instructions



It is NOT necessary to remove the fan out of the DucoBox.

<p style="text-align: center;">Step 1: Remove the inlet ring from the existing fan by loosening 3 screws.</p> 	<p style="text-align: center;">Step 2: Fan + spare part: 0000-4941 (Inlet ring + Flowgrid) Screw the new inlet ring onto the fan. Then click the flow optimiser onto the inlet ring.</p> 
---	--

Copyright rules: all rights reserved - Translation of the instructions from Dutch

Changes based on technical improvements reserved. For information regarding warranty, maintenance, technical data, etc., see www.duco.eu. Installation, connection, maintenance and repairs are to be carried out by an accredited installer. The electronic components of this product may be live. Avoid contact with water.

Vero DUCO - Handelsstraat 19 - 8630 Veurne - Belgium
 tel +32 58 33 00 33 - info@duco.eu - www.duco.eu

